

# Killer B Motorsport

## EJ Oil Fill Tube Installation Guide

BEFORE:



AFTER:



### What's in the box

- Killer B Motorsport Oil Fill Tube
- (2) M6 blue fasteners
- Brochure
- Sticker

### Tools needed

-10mm socket

-5mm hex socket

-Socket extension

-Socket wrench, 1/4" or 3/8" drive

-5 minutes

1. Open hood.
2. Loosen and remove the 2 M6 (10MM) fasteners securing the oil fill tube to the rocker cover.
3. Loosen and remove the 1 M6 (10MM) fastener securing the bottom of the mounting bracket to the rocker cover.
4. Prepare sealing surface: carefully wipe any debris and/or oil from the rocker cover sealing surface, taking extra care not to introduce any contaminants into your engine.
5. Make sure your Killer B Motorsport Oil Fill Tube is clean and ready for installation.
6. Wipe a small amount of engine oil on the o-ring of the fill tube.
7. Insert the fill tube into the rocker cover opening.
8. Gently work the tube into place, making sure you do not pinch the o-ring (the oil helps reduce pinching)
9. Thread in the (2) BLUE M6 fasteners included with the kit by hand.
10. Torque fasteners to 4.8 FT-LBS (57.6 IN-LBS)
11. Remove the remaining fastener and bracket from your OEM oil fill tube.
- 12a. For 2008+ STI engines: Change over the existing mounting bracket from your OEM filler tube and install it on your new Killer B Motorsport Oil Fill Tube.
- 12b. For NON 2008+ STI engines: mount the supplied bracket to your Killer B Motorsport Oil Fill Tub.
13. Torque the mounting bracket hardware to 4.8 FT-LBS (57.6 IN-LBS)
14. Remove the oil filler cap from your old filler tube, screw it into the Killer B Motorsport Tube.
15. Enjoy easier oil changes on your front mount EJ!